




NJORD



NJORD-27001
It. ATC541A

TECHNICAL FEATURES: 110-240V~, 50/60Hz, 25W

Made in PRC

Imported by Labor Pro srl - Empoli (Firenze) ITALY
and distributed by:

Njord | www.getnjord.com
Mogelhoj 8 | DK-8520 Lystrup



BEARD STRAIGHTENER
MANUAL

ENGLISH

Read the notes in the following booklet carefully as they provide important information regarding safety, use and maintenance.

This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance.

Cleaning and user maintenance shall not be made by children without supervision.

When the appliance is used in a bathroom, unplug it after use since the proximity of water presents a hazard even when the appliance is switched off.

For additional protection, the installation of a residual current device (RCD) having a rated residual operating current not exceeding 30 mA is advisable in the electrical circuit supplying the bathroom.

Ask your installer for advice.



This symbol on the appliance means "Do not use this appliance near bathtubs, showers, basins or other vessels containing water."

Never operate the appliance if it is not working properly.

If the power cord or plug is damaged, it must be replaced by the manufacturer, its service department or a qualified technician in order to avoid hazardous situations.

Burn hazard. Keep appliance out of reach from young children, particularly during use and cool down.

When the appliance is connected to the power supply, never leave it unattended.

Always place the appliance with the stand, if any, on a heat-resistant, stable flat surface.

Safety advises

After removing the packaging, check the integrity of the appliance. If in doubt, do not use the appliance, and contact only an authorized service center.

Do not leave the packaging (plastic bags, cardboard boxes, staples) within the reach of children, as it is a potential source of danger.

Warnings

Do not use the device for purposes other than beard care.

Do not connect or disconnect the power plug from the wall socket with wet hands

Do not use with the cable wrapped around yourself or around the appliance.

Do not wrap the cable around the appliance before putting it away.

Do not use the appliance if the power plug is loose in the electrical socket.

Fully insert the plug into the electrical socket. Do not use an extension cord.

ENGLISH

Do not use near flammable materials, such as alcohol, petrol, thinners, sprays, hair care products or nail polish removers.

Do not attempt to modify or repair the product.

Do not damage, modify, bend, pull or twist the cable. Do not place heavy objects on the cable or compress it.

Do not store the appliance in a bathroom or any other place with high humidity.

Also, do not place it where water may drip, for example above the washbasin cabinet). Do not immerse the appliance in water.

Do not touch the heating combs of the plate because they are hot.

Any contact with the skin can cause burns.

Warning

Always ensure that the appliance is powered from an electrical source whose voltage matches that shown on the appliance.

Disconnect the appliance from the mains by gripping the plug, not pulling on the cable.

Use the appliance only on clean, dry and tangle-free beard.

Features

- The plate has a special shape similar to a brush: it is equipped with heated teeth that allow greater traction of the beard hair for fast and effective straightening.
- Small and lightweight: it can straighten every part of the beard.
- 2 temperatures: 170°C or 190°C.
- Equipped with an anti-burn coating.
- Tourmaline ceramic plate, measuring 25x85 mm.
- Weight: 194g.

How to use it

1. Connect the appliance to the power socket and move the power button to ON. The status LED will turn on to indicate that the appliance is in operation.
2. Select the first temperature (GREEN status LED - 170 ° C) in case of a normal beard.
3. Select the second temperature (RED status LED - 190 ° C) if it is shaggy and curly.
4. Proceed by straightening the beard.
5. At the end, turn off the appliance and unplug it from the power socket.

DANSK

Læs venligst følgende brugsanvisning omhyggeligt, da den giver vigtige oplysninger om sikkerhed, brug og vedligeholdelse.

Dette apparat kan bruges af børn fra 8 år og derover og personer med nedsatte fysiske, sensoriske eller mentale evner eller mangel på erfaring og viden, hvis de har fået supervision eller instruktion i brugen af apparatet på en sikker måde og forstår de relaterede farer ved brugen af det.

Børn må ikke lege med apparatet.

Rengøring og vedligeholdelse må ikke udføres af børn uden opsyn.

Når du bruger apparatet i badeværelset, skal du trække stikket ud umiddelbart efter brug, da vand udgør en risiko, selv når enheden er slukket.

For at forbedre sikkerheden anbefaler vi at installere en differential afbryder (RCD eller lifesaver) med en reststrøm, der ikke overstiger 30mA.

For yderligere information, kontakt venligst en autoriseret elektriker.



Dette symbol på apparatet betyder "Brug ikke apparatet i nærheden af håndvaske, badekar, brusere eller beholdere fyldt med vand."

Betjen aldrig apparatet, hvis det ikke fungerer korrekt.

Hvis ledningen eller stikket er beskadiget, skal det udskiftes af producenten, dennes serviceafdeling eller en kvalificeret tekniker for at undgå farlige situationer.

Forbrændingsfare: Opbevares utilgængeligt for børn og spædbørn, især under brug og afkøling.

Når apparatet er tilsluttet, må det aldrig efterlades uden opsyn.

Placer altid apparatet på en stabil og varmebestandig plan overflade.

Sikkerhedsråd

Efter at have fjernet emballagen, skal du kontrollere at apparatet ser funktionsdygtigt ud. Hvis du er i tvivl, så brug ikke apparatet, og kontakt kun et autoriseret servicecenter.

Efterlad ikke emballagen (plastikposer, papkasser, hæftklamrer) inden for rækkevidde af børn, da det er en potentiel kilde til fare.

Advarsler

Brug ikke enheden til andre formål end skægpleje.

Tilslut eller tag ikke stikket ud af stikkontakten med våde hænder

Må ikke bruges med kablet viklet rundt om dig selv eller apparatet.

Vikl ikke kablet rundt om apparatet, før du lægger det væk.

Brug ikke apparatet, hvis stikket er løst i stikkontakten.

Sæt stikket helt ind i stikkontakten. Brug ikke en forlængerledning.

DANSK

Brug ikke apparatet i nærheden af brændbare materialer såsom alkohol, benzin, fortyndere, sprays, hårpåleprodukter eller neglelakfjernere.

Forsøg ikke at ændre eller reparere produktet.

Kablet må ikke beskadiges, modificeres, bøjes, trækkes eller drejes. Anbring ikke tunge genstande på kablet eller komprimer det.

Opbevar ikke apparatet på et badeværelse eller andre steder med høj luftfugtighed.

Placer det heller ikke, hvor der kan dryppe vand. Nedsenk ikke apparatet i vand.

Rør ikke ved apparatets børste-del, da den er varm. Enhver kontakt med huden kan forårsage forbrændinger.

Sørg altid for, at apparatet får strøm fra en elektrisk kilde, hvis spænding svarer til den, der er vist på apparatet.

Afbryd apparatet fra stikkontakten ved at tage fat i stikket, ikke trække i ledningen.

Brug kun apparatet på rent, tørt og friseret skæg.

Funktioner

- Pladen har en speciel form, der ligner en børste: den er udstyret med opvarmede tænder, der tillader større trækraft i skægget for hurtig og effektiv glatning.
- Lille og let: den kan glatte alle områder af skægget.
- 2 temperaturer: 170°C eller 190°C.
- Udstyret med en anti-burn belægning.
- Turmalin keramisk plade, som måler 25x85 mm.
- Vægt: 194g.

Sådan bruges det

1. Tilslut apparatet til stikkontakten, og slub tænd/sluk-knappen til ON. LED indikatorlampen lyser for at indikere, at apparatet er i drift.
2. Vælg den første temperatur (GRØN indikatorlampe - 170 ° C) ved et normalt skæg.
3. Vælg den anden temperatur (RØD indikatorlampe - 190 ° C), hvis skægget er pjusket og krøllet.
4. Glat skægget.
5. Til sidst skal du slukke for apparatet og tage stikket ud af stikkontakten.